

CHISEL SUBSOILER PLOW

EST/MATIC 300 G3 (WIHTOUT BOX)

Code: 0501091499
Series: S-0115
Revision: 00
Revision Date: FEVEREIRO/2016

PARTS CATALOGUE

CIVEMASA

A solid orange horizontal bar located at the top left of the page.

PRODUCTS


Code	Description
0121700013	ESTAC 300 G3 11H DC RD S-0115
0121700017	ESTAC 300 G3 15H DC RD R/DUP S-0115
0121700011	ESTAC 300 G3 17H DC RD S-0115
0121700010	ESTAC 300 G3 21H DC RD S-0115
0121700019	ESTAC 300 G3 23H DC RD S-0115

ATTENTION: IMPORTANT

CIVEMASA reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.


INDEX

0909091853	FRAME 9/11/13/15 H	1
0909091854	FRAME 17/19/21/23 H	2
0511053317	RIGHT WHEEL ASSY	3
0511053318	LEFT WHEEL ASSY	4
0909094642	WHEEL ASSY	5
0501051142	CARRYING WHEEL HUB	6
0511048088	DRAWBAR JACK	7
0521041963	ROD WITH ARM/DISARMENT	8
0501052885	3/4 UNC X 450 FASTENER ASSY	9
0521045737	HYDRAULIC CILINDER 44,45 X 85,72 X 515 X 205	10
0521040915	HYDRAULIC CYLINDER 44,45 X 85,7 X 515 X 203	11
0521040391	HYDRAULIC CYLINDER 53,98 X 101,6 X 515 X 203	12
0521045333	BLADE DISC 20	13
0511058648	HUB WITH 20" DISC BLADE	14
0521044408	DRAWBAR WITH HITCH	15
0501047356	ESTABILIZER ASSY	16
0501054088	DRAWBAR STABILIZER ASSEMBLY	17
0521045085	BREAKER ROLLER ARM ASSY	18
0521045127	BREAK ROLLER	19
0521045128	CAGE ROLLER ASSEMBLY	20
0521045129	BREAK ROLLER	21
0521044951	BREAK ROLLER	22
0501042180	BEARING DUROMARK OL 192,5 X 1.1/4 IT	23
0909091851	HYDRAULIC CIRCUIT WITH SEED BOX	24
0909091852	HYDRAULIC CIRCUIT WITH SEED BOX	25
0501053834	MALE QUICK COUPLER	26




Item	Code	Description	See page	09	11	13	15
01	0521064899	FRAME 09-15H		01	01	01	01
02	0511053317	RIGHT WHEEL ASSY	3	01	01	01	01
03	0511053318	LEFT WHEEL ASSY	4	01	01	01	01
04	0521064087	CARRYING-WHEELS PIVOT		02	02	02	02
05	0521063252	50,85 X 332 AXLE		02	02	02	02
06	0503010073	3/8 X 3-1/2 COTTERPIN		02	02	02	02
07	0521064086	ADJUSTMENT WHEEL		02	02	02	02
08	0541018672	COUNTERNUT		02	02	02	02
09	0521015342	WASHER SPACER		04	04	04	04
10	0521045737	HYDRAULIC CILINDER 44,45 X 85,72 X 515 X 205	10	02	02	02	04
11	0503010026	3/8" NUT		09	11	13	15
12	0521012538	1.2" X 3.5" COUPLING SHAFT		02	02	02	02
13	0521010547	1.2" X 6.5" COUPLING SHAFT		02	02	02	02
14	0503010523	1/4" X 2" COTTERPIN		04	04	04	04
15	0521044408	DRAWBAR WITH HITCH	15	01	01	01	01
16	0521045127	BREAK ROLLER	19	02	00	00	00
17	0521045128	CAGE ROLLER ASSEMBLY	20	00	02	00	00
18	0521045129	BREAK ROLLER	21	00	00	02	00
19	0521044951	BREAK ROLLER	22	00	00	00	02
20	0521041963	ROD WITH ARM/DISARMENT	8	09	11	13	15
21	0521065568	EXTENSION		01	00	00	00
22	0521065408	EXTENSION		00	01	00	00
23	0521065569	EXTENSION		00	00	01	00
24	0521065251	EXTENSION		00	00	00	01
25	0503062010	750 X 16-12L ASSY WHEEL AND TIRE		04	04	04	04
26	0521064117	EXTENSION		00	02	00	00
27	0521064120	EXTENSION		00	00	02	00
28	0521064135	EXTENSION		00	00	00	02
29	0521045333	BLADE DISC 20	13	09	11	13	15
30	0501047356	ESTABILIZER ASSY	16	01	01	01	01
31	0521045085	BREAKER ROLLER ARM ASSY	18	04	04	04	04

Item	Code	Description	See page	09	11	13	15
32	0501052885	3/4 UNC X 450 FASTENER ASSY	9	09	11	13	15
33	0501068088	OIL TUBE		01	01	01	01
34	0521065068	HOSE FIXER SUPPORT		03	03	03	03
35	0502012702	BODY SUPPORT CLAMP		06	06	06	06
36	0502012796	BLADE DISC SUPPORT ASSY		09	11	13	15
37	0571011609	FIXER PLATE CUTTING DISC		26	30	42	46
38	0571017219	EXTENSION LOCK		02	02	02	02
39	0521065149	EXTENSION		02	02	04	04
40	0501010125	3/4" X 2-1/2" BOLT		08	24	24	24
41	0503010023	3/4" SPRING WASHER		60	84	108	116
42	0503010014	3/4" NUT		08	24	24	24
43	0571012422	COUPLING SHAFT		02	02	02	02
44	0503010523	1/4" X 2" COTTERPIN		02	02	02	02
45	0521010578	COUPLING SHAFT		01	01	01	01
46	0503010571	1/4" X 1.1/2 COTTERPIN		02	02	02	02
47	0521010582	COUPLING SHAFT		01	01	01	01
48	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		06	06	06	06
49	0503010180	7/16" SPRING WASHER		06	06	06	06
50	0501069080	COUPLING SHAFT		01	01	01	01
51	0503031035	HITCH PIN CLIP		01	01	01	01
52	0503011268	3/8" X 2-1/2" BOLT		09	11	13	15
53	0503014744	3/4 UNF X 7.1/2 C S G.7 ZN BOLT		52	60	84	92
54	0503010335	3/4"NUT		52	60	84	92
55	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		18	22	26	30
56	0503011082	C1/2" X 1.3/4" SCREW		03	03	03	03
57	0503010019	1/2" SPRING WASHER		03	03	03	03
58	0503010060	1/2" NUT		03	03	03	03
59	0511015255	FLAT WASHER		04	04	04	04
60	0503010839	03"X 0.6" SPRING PIN		02	02	02	02




Item	Code	Description	See page	17	19	21	23
01	0521064936	FRAME 17-21H		01	01	01	01
02	0511053317	RIGHT WHEEL ASSY	3	02	02	02	02
03	0511053318	LEFT WHEEL ASSY	4	02	02	02	02
04	0521064086	ADJUSTMENT WHEEL		04	04	04	04
05	0541018672	COUNTERNUT		04	04	04	04
06	0503010839	03"X 0.6" SPRING PIN		04	04	04	04
07	0521063252	50,85 X 332 AXLE		04	04	04	04
08	0521015342	WASHER SPACER		08	08	08	08
09	0503010073	3/8 X 3-1/2 COTTERPIN		04	04	04	04
10	0521064087	CARRYING-WHEELS PIVOT		04	04	04	04
11	0521045737	HYDRAULIC CILINDER 44,45 X 85,72 X 515 X 205	10	04	04	04	04
12	0503010026	3/8" NUT		17	19	21	23
13	0521012538	1.2" X 3.5" COUPLING SHAFT		04	04	04	04
14	0521010547	1.2" X 6.5" COUPLING SHAFT		04	04	04	04
15	0503010523	1/4" X 2" COTTERPIN		08	08	08	08
16	0521043174	DRAWBAR ASSY		01	01	01	01
17	0521045127	BREAK ROLLER	19	00	00	02	00
18	0521045128	CAGE ROLLER ASSEMBLY	20	03	01	02	04
19	0521045129	BREAK ROLLER	21	00	02	00	00
20	0521041963	ROD WITH ARM/DISARMENT	8	17	19	21	23
21	0521065573	EXTENSION		01	00	00	00
22	0521065572	EXTENSION		00	01	00	00
23	0521065570	EXTENSION		00	00	01	00
24	0521065739	EXTENSION		00	00	00	01
25	0521065741	EXTENSION		00	00	00	01
26	0521065740	EXTENSION		00	00	01	00
27	0503062010	750 X 16-12L ASSY WHEEL AND TIRE		04	04	04	04
28	0521064117	EXTENSION		00	02	00	00
29	0521064120	EXTENSION		00	00	02	00
30	0521064135	EXTENSION		00	00	00	02
31	0521045333	BLADE DISC 20	13	17	19	21	23


Item	Code	Description	See page	17	19	21	23
32	0501054088	DRAWBAR STABILIZER ASSEMBLY	17	01	01	01	01
33	0501052885	3/4 UNC X 450 FASTENER ASSY	9	17	19	21	23
34	0502012796	BLADE DISC SUPPORT ASSY		17	19	21	23
35	0571011609	FIXER PLATE CUTTING DISC		50	62	66	70
36	0521045085	BREAKER ROLLER ARM ASSY	18	06	06	08	08
37	0511048088	DRAWBAR JACK	7	01	01	01	01
38	0501072676	OIL DISTRIBUTOR BODY		02	02	02	02
39	0521065068	HOSE FIXER SUPPORT		04	04	04	04
40	0502012702	BODY SUPPORT CLAMP		10	10	10	10
41	0571017219	EXTENSION LOCK		02	02	02	02
42	0521065149	EXTENSION		04	06	06	06
43	0501010125	3/4" X 2-1/2" BOLT		08	24	26	26
44	0503010023	3/4" SPRING WASHER		108	148	158	166
45	0503010014	3/4" NUT		08	24	26	26
46	0571012422	COUPLING SHAFT		04	04	04	04
47	0503010523	1/4" X 2" COTTERPIN		06	06	06	06
48	0521010780	1.2" X 4.5" COUPLING SHAFT		01	01	01	01
49	0521012536	COUPLING SHAFT		01	01	01	01
50	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		10	10	10	10
51	0503010180	7/16" SPRING WASHER		10	10	10	10
52	0561014251	COUPLING SHAFT		01	01	01	01
53	0503030285	HITCH PIN CLIP		01	01	01	01
54	0503011268	3/8" X 2-1/2" BOLT		17	19	21	23
55	0503014744	3/4 UNF X 7.1/2 C S G.7 ZN BOLT		100	124	132	140
56	0503010335	3/4"NUT		100	124	132	140
57	0503011082	C1/2" X 1.3/4" SCREW		03	03	03	03
58	0503010019	1/2" SPRING WASHER		03	03	03	03
59	0503010060	1/2" NUT		03	03	03	03
60	0511015255	FLAT WASHER		04	04	08	08




Item	Code	Description	See page	QT
001	0503010002	1800 GREASE FITTING		02
002	0503010018	5/32 X 1-1/2 COTTERPIN		01
003	0503011444	SPRING WASHER		04
004	0503010358	5/16" X 5/8" BOLT		04
005	0501051142	CARRYING WHEEL HUB	6	01
006	0503030009	1" CASTLE NUT		01
007	0502020591	PROTECCION COVER		01
008	0501016545	FLAT WASHER		01
009	0521064084	WHEELS RIGHT EST/MATIC 300		01




Item	Code	Description	See page	QT
001	0503010002	1800 GREASE FITTING		02
002	0503010018	5/32 X 1-1/2 COTTERPIN		01
003	0503011444	SPRING WASHER		04
004	0503010358	5/16" X 5/8" BOLT		04
005	0501051142	CARRYING WHEEL HUB	6	01
006	0503030009	1" CASTLE NUT		01
007	0502020591	PROTECCION COVER		01
008	0501016545	FLAT WASHER		01
009	0521064085	CARRYNG-WHEELS LEFT EST/MATIC 300		01




Item	Code	Description	See page	QT
01	0511053317	RIGHT WHEEL ASSY	3	01
02	0511053318	LEFT WHEEL ASSY	4	00
03	0503010002	1800 GREASE FITTING		02
04	0503010018	5/32 X 1-1/2 COTTERPIN		01
05	0503011444	SPRING WASHER		04
06	0503010358	5/16" X 5/8" BOLT		04
07	0501051142	CARRYING WHEEL HUB	6	01
08	0503030009	1" CASTLE NUT		01
09	0502020591	PROTECCION COVER		01
10	0501016545	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0501110728	WHEEL HUB		01
01A	0502011121	CARRYING WHEEL HUB		01
01B	0501010127	9/16" X 1-7/8" LUG BOLT		06
01C	0503010035	9/16" CONIC NUT		06
02	0503010037	30207 ROLLER BEARING		01
03	0503010006	32210 ROLLER BEARING		01
04	0503012928	SEAL		01




Item	Code	Description	See page	QT
01	0503062227	DRAWBAR JACK		01




Item	Code	Description	See page	QT
001	0502011861	FIXER BASE UPPER	01	
002	0502011864	AST/MATIC 450 RESET	01	
003	0521017724	1" X 6.2" COUPLING SHAFT	01	
004	0503010571	1/4" X 1.1/2" COTTERPIN	04	
005	0502011863	LOWER BASE FIXER	01	
006	0503010014	3/4" NUT	04	
007	0503011442	3/4" SPRING WASHER	04	
008	0503012729	3/4" X 6-3/4" BOLT	04	
009	0521017725	1" X 7.4" COUPLING SHAFT	01	
010	0503010002	1800 GREASE FITTING	01	
011	0503031574	6.9" X 0.8" X 0.1" EXTENSION SPRING	01	
012	0503010004	1890 GREASE FITTING	02	
013	0503010691	1/4" GREASE FITTING	01	
014	0521063902	ROD BODY DISASSEMBLE	01	
015	0521063903	POINT 16 X 2 X 5/8	01	
016	0503011265	10MM X 50MM SPRING PIN	02	
017	0503010775	SPRING PIN	02	




Item	Code	Description	See page	QT
01	0521015426	3/4" X 18" FASTENER		01
02	0502011860	SPRING LOWER SUPPORT		01
03	0503031575	2.5"X 12" X 0.5" COMPRESSION SPRING		02
04	0502011866	SPRING UPPER SUPPORT		01
05	0503010014	3/4" NUT		04




Item	Code	Description	See page	QT
01	0511061588	3.4" X 16" CYLINDER CASE		01
02	0503010042	2-214 N 3006-9B O'RING		01
03	0503010063	1" SELF-ALIGNING NUT		01
04	0503010761	D-1750 SCRAPER RING		01
05	0503030385	CYLINDER PLUG N-002		02
06	0571019711	RING SUPPORT		01
07	0571019710	1.7" X 3.4" PISTON		01
08	0503017935	RING		01
09	0503017936	RING		01
10	0503017938	RING GUIDE		01
11	0503017937	GASKET		01
12	0503017940	8-337 BACK-UP RING		02
13	0503017939	2-337 N 3006-9B O' RING		02
14	0571019709	DETACHABLE COVER		01
15	0521066243	TURNBUCKLE		01
16	0503010002	1800 GREASE FITTING		01
17	0503018144	RING		01
18	0511034218	CYLINDER REPAIR KIT 44,45 X 85,72		01




Item	Code	Description	See page	QT
01	0511068372	85,72 X 203 CYLINDER CASE		01
02	0502011847	1.7" X 3.4" PISTON		01
03	0502010781	RING SUPPORT		01
04	0502010993	DETACHABLE COVER		01
05	0503010042	2-214 N 3006-9B O'RING		01
06	0503010063	1" SELF-ALIGNING NUT		01
07	0503010948	W4-3346-590 PK RING G.E		01
08	0503010949	W2-2000-500 PK RING G.E		01
09	0503010990	GASKET		01
10	0503010761	D-1750 SCRAPER RING		01
11	0503010976	2-336 N 3006-9B O'RING		01
12	0503011060	8-336 BACK-UP RING		01
13	0503030384	CON PLUG N-001		02
14	0503012509	GASKET		02
15	0521063254	44,45 X 450 TURNBUCKLE		01
16	0503010002	1800 GREASE FITTING		01
17	0501035169	CYLINDER REPAIR KIT 44,45 X 85,72		01




Item	Code	Description	See page	QT
01	0511068373	101,6 X 203 CYLINDER CASE		01
02	0521062882	53,98 X 448 TURNBUCKLE		01
03	0502011249	PISTON		01
04	0502011250	RING OF SUPPORT		01
05	0502010017	4" HEAD		01
06	0503010817	1.1/4" SELF LOCKING NUT		01
07	0503010345	2-218 N 3006-9B O'RING		01
08	0503012725	GASKET		01
09	0503010994	W2-4000-500 PK RING G.E		01
10	0503010043	PACKING 3750-3250		01
11	0503010338	2-342 N 3006-9B O'RING		01
12	0503011061	8-342 BACK-UP RING		01
13	0503010319	D-2125 SCRAPER		01
14	0503010314	GASKET		01
15	0503010973	W2-2500-500 PK O'RING G.E		01
16	0503010002	1800 GREASE FITTING		01
17	0503030384	CON PLUG N-001		02
18	0511031218	CYLINDER REPAIR KIT 53,98 X 101,6		01




Item	Code	Description	See page	QT
01	0521065732	BLADE DISC AXLE ASSY		01
02	0511060915	ROD SPRING		01
03	0503031679	COMPRES SPRING		01
04	1902020393	SPRING UPPER SUPPORT		01
05	0511061576	SPRING GUIDE		01
06	0503011198	C3/4" X 6" SCREW		02
07	0503011442	3/4" SPRING WASHER		02
08	0503010014	3/4" NUT		04
09	0521010452	SLEEVE		02
10	0502012817	DISC BLADE SUPPORT		01
11	0571018178	DISC BLADE ARM		01
12	0503010361	SPRING PIN		01
13	0503010002	1800 GREASE FITTING		01
14	0541018684	FLAT WASHER		01
15	0511058648	HUB WITH 20" DISC BLADE	14	01
16	0521065733	DISC BLADE ARM		01




Item	Code	Description	See page	QT
01	0511056909	DISC BOX CUT WITHOUT DISC		01
02	0603027851	20" X 0.2" FLAT PLAIN DISC		01




Item	Code	Description	See page	QT
01	0511055614	HITCH		01
01A	0502040853	HITCH JOINT		01
01B	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
01C	0503010396	501060 CLAMPING RING (FOR AXLE)		01
02	0503010002	1800 GREASE FITTING		01
03	0503016482	BOLT		02
04	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
05	0503010010	1/4" X 2.1/2" COTTERPIN		01
06	0503033731	COMPRESSION SPRING LEFT		02
07	0503011331	3/8 BALL		02
08	0571016503	FIXER BOLT		01
09	0521065003	HEADER S/ HITCH		01




Item	Code	Description	See page	QT
01	0501068095	850 ADJUSTMENT NUT		01
02	0501068096	RIGTH TURNBUCKLE		01
03	0541018673	COUNTERNUT		01
04	0541018672	COUNTERNUT		01
05	0501068097	LEFT TURNBUCKLE		01
06	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511063786	EXTENDER 950		01
02	0511063787	RIGHT EXTENDER SPINDLE R1.1/2 X 432		01
03	0511063788	LEFT EXTENDER SPINDLE R1.1/2 X 432		01
04	0541018672	COUNTERNUT		01
05	0541018673	COUNTERNUT		01
06	0503010002	1800 GREASE FITTING		02



Item	Code	Description	See page	QT
01	0521065531	PRESS ROLLER ARM	01	
02	0521065532	ROD SPRING	01	
03	0501010059	1.5/8 NUT	04	
04	0571011377	SPRING GUIDES SLEVE	02	
05	0521063151	TRUNNION LOCK ARTICULATOR SPRING ROD	02	
06	0571011378	TRUNNION ARTICULATOR SPRING ROD	01	
07	0521062685	ARTICULATION AXIS	01	
08	0521065529	FIXATION SUPPORT	01	
09	0503014744	3/4 UNF X 7.1/2 C S G.7 ZN BOLT	02	
10	0503010023	3/4" SPRING WASHER	02	
11	0503010335	3/4"NUT	02	
12	0571011609	FIXER PLATE CUTTING DISC	01	
13	0521010578	COUPLING SHAFT	01	
14	0503010019	1/2" SPRING WASHER	02	
15	0503010010	1/4" X 2.1/2" COTTERPIN	01	
16	0521010808	1.4" X 5.8" COUPLING SHAFT	01	
17	0503012267	5/16" X 3" COTTER PIN	02	
18	0511019685	FLAT WASHER	02	
19	0503031575	2.5"X 12" X 0.5" COMPRESSION SPRING	01	
20	0503010002	1800 GREASE FITTING	01	
21	0503010920	1/2" X 1.1/2" BOLT	02	
22	0503010060	1/2" NUT	02	




Item	Code	Description	See page	QT
01	0501042180	BEARING DUROMARK OL 192,5 X 1.1/4 IT	23	02
02	0503018575	WASHER CONCAVE		02
03	1902010835	1-1/4" EXTERNAL AXLE WASHER		04
04	0501010752	1.1/4" X 500 AXLE		02
05	0501010087	1.1/4" NUT		04
06	0501010455	1.1/4" NUT LOCK		04
07	0503010060	1/2" NUT		04
08	0503010013	5/8" NUT		04
09	0503011445	SPRING WASHER		04
10	0501010161	1/2" X 1.1/4" BOLT		04
11	0503010232	5/8" X 1.3/4" BOLT		04
12	0501058802	5/8 UNC X 2.3/4 BOLT ASSY		04
12A	0503015154	5/8" X 2.3/4" BOLT		04
12B	0501010947	5/8 NUT LOCK		04
12C	0501012140	FLAT WASHER		04
12D	0503010013	5/8" NUT		08
13	0503011440	SPRING WASHER		04
14	0521065253	ROLLER FIXER		02
15	0503010013	5/8" NUT		08
16	0571017230	FIXER PLATE		02
17	0501013867	BOLT 5/8 UNC X 6 CS G.5 ZN		08
18	0503010027	5/8" SPRING WASHER		08
19	0503010002	1800 GREASE FITTING		02
20	0521062673	BRACKET MOBILE FIXER ROLLER		01
21	0521065546	ROLLER		01
22	0521065549	SUPPORT		01




Item	Code	Description	See page	QT
001	0501046922	AGRICULTURAL BEARING DM OL 192.5 X 1.1/4 IMPLEMENT		02
002	0531018575	WASHER CONCAVE		02
003	1902010835	1-1/4" EXTERNAL AXLE WASHER		04
004	0501010752	1.1/4" X 500 AXLE		02
005	0501010087	1.1/4" NUT		04
006	0501010455	1.1/4" NUT LOCK		04
007	0503010060	1/2" NUT		04
008	0503010013	5/8" NUT		04
009	0503011445	SPRING WASHER		04
010	0501010161	1/2" X 1.1/4" BOLT		04
011	0503010232	5/8" X 1.3/4" BOLT		04
012	0501058802	5/8 UNC X 2.3/4 BOLT ASSY		04
012A	0503015154	5/8" X 2.3/4" BOLT		01
012B	0501010947	5/8 NUT LOCK		01
012C	0501012140	FLAT WASHER		01
012D	0503010013	5/8" NUT		02
013	0503011440	SPRING WASHER		04
014	0521065253	ROLLER FIXER		02
015	0503010013	5/8" NUT		08
016	0571017230	FIXER PLATE		02
017	0501013867	BOLT 5/8 UNC X 6 CS G.5 ZN		08
018	0503010027	5/8" SPRING WASHER		08
019	0503010002	1800 GREASE FITTING		02
020	0521062673	BRACKET MOBILE FIXER ROLLER		01
021	0521065547	ARM ROLLE ASSY		01
022	0521065550	BREAK ROLLER SUPPORT		01

BREAK ROLLER




Item	Code	Description	See page	QT
001	0501046922	AGRICULTURAL BEARING DM OL 192.5 X 1.1/4 IMPLEMENT		02
002	0531018575	WASHER CONCAVE		02
003	1902010835	1-1/4" EXTERNAL AXLE WASHER		04
004	0501010752	1.1/4" X 500 AXLE		02
005	0501010087	1.1/4" NUT		04
006	0501010455	1.1/4" NUT LOCK		04
007	0503010060	1/2" NUT		04
008	0503010013	5/8" NUT		04
009	0503011445	SPRING WASHER		04
010	0501010161	1/2" X 1.1/4" BOLT		04
011	0503010232	5/8" X 1.3/4" BOLT		04
012	0501058802	5/8 UNC X 2.3/4 BOLT ASSY		04
012A	0503015154	5/8" X 2.3/4" BOLT		01
012B	0501010947	5/8 NUT LOCK		01
012C	0501012140	FLAT WASHER		01
012D	0503010013	5/8" NUT		02
013	0503011440	SPRING WASHER		04
014	0521065253	ROLLER FIXER		02
015	0503010013	5/8" NUT		08
016	0571017230	FIXER PLATE		02
017	0501013867	BOLT 5/8 UNC X 6 CS G.5 ZN		08
018	0503010027	5/8" SPRING WASHER		08
019	0503010002	1800 GREASE FITTING		02
020	0521062673	BRACKET MOBILE FIXER ROLLER		01
021	0521065548	BREAK ROLLER SUPPORT		01
022	0521065551	BREAK ROLLER SUPPORT 2030 EST/MATIC		01


BREAK ROLLER




Item	Code	Description	See page	QT
001	0501046922	AGRICULTURAL BEARING DM OL 192.5 X 1.1/4 IMPLEMENT		02
002	0531018575	WASHER CONCAVE		02
003	1902010835	1-1/4" EXTERNAL AXLE WASHER		04
004	0501010752	1.1/4" X 500 AXLE		02
005	0501010087	1.1/4" NUT		04
006	0501010455	1.1/4" NUT LOCK		04
007	0503010060	1/2" NUT		04
008	0503010013	5/8" NUT		04
009	0503011445	SPRING WASHER		04
010	0501010161	1/2" X 1.1/4" BOLT		04
011	0503010232	5/8" X 1.3/4" BOLT		04
012	0501058802	5/8 UNC X 2.3/4 BOLT ASSY		04
012A	0503015154	5/8" X 2.3/4" BOLT		01
012B	0501010947	5/8 NUT LOCK		01
012C	0501012140	FLAT WASHER		01
012D	0503010013	5/8" NUT		02
013	0503011440	SPRING WASHER		04
014	0521065253	ROLLER FIXER		02
015	0503010013	5/8" NUT		08
016	0571017230	FIXER PLATE		02
017	0501013867	BOLT 5/8 UNC X 6 CS G.5 ZN		08
018	0503010027	5/8" SPRING WASHER		08
019	0503010002	1800 GREASE FITTING		02
020	0521062673	BRACKET MOBILE FIXER ROLLER		01
021	0521065479	DESTROYER ROLLER 2290		01
022	0521065480	BREAK ROLLER SUPPORT		01




Item	Code	Description	See page	QT
01	0502010539	HOUSING DM		01
02	0503010111	30210 ROLLER BEARING		02
03	0502040218	AXLE		01
04	0503030013	4.4" X 3.5" X 0.004" JOINT		02
05	0503030684	4.4" X 3.5" X 0.004" JOINT		01
06	0502020424	HOUSING CAP		01
07	0503010134	3/8" X 1" BOLT		04
08	0503030026	SEAL LP JB-253		02
09	0502010541	SEAL RETAINER		02
10	0502010070	OUTER FLANGE		01
11	0502010071	INNER FLANGE		01
12	0503010856	OIL PLUG		01



Item	Code	Description	See page	QT
01	0521040915	HYDRAULIC CYLINDER 44,45 X 85,7 X 515 X 203	11	01
02	0521040391	HYDRAULIC CYLINDER 53,98 X 101,6 X 515 X 203	12	01
03	0501068088	OIL TUBE		01
04	0501010617	3/4" NIPPLE		04
05	0503010190	2-114 N 3006-9B O'RING		04
06	0501080348	3/8 X 1200 TR-TC HOSE		01
07	0501080746	TC-TC HOSE ASSY		01
08	0501080436	3/8 X 1600 TR-TC HOSE		01
09	0501080384	TR-TM HOSE ASSY		02
10	0501053834	MALE QUICK COUPLER	26	02



Item	Code	Description	See page	QT
01	0521040915	HYDRAULIC CYLINDER 44,45 X 85,7 X 515 X 203	11	02
02	0521040391	HYDRAULIC CYLINDER 53,98 X 101,6 X 515 X 203	12	02
03	0501072676	OIL DISTRIBUTOR BODY		02
04	0501010617	3/4" NIPPLE		08
05	0503010190	2-114 N 3006-9B O'RING		08
06	0501080025	3/8 X 1400 TR-TC HOSE		02
07	0501081108	3/8 X 1400 TC-TC HOSE		02
08	0501080515	HOSE 3/8 X 3400 TR-TC		02
09	0501080509	TR-TM HOSE ASSY		02
10	0501053834	MALE QUICK COUPLER	26	02



Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01



civemasa

Technical Publications | Elaboration and Revision
ALESSANDRA PATRICIA KAWAHARA CARRILI

www.civemasa.com.br

